

ML[®] INSTALLATION INSTRUCTIONS

Patent #7,386,922

REQUIRED TOOLS



Recognized for mechanical load testing per UL2703



1/4" Hex Driver



Dial indicator torque wrench


STEP #1

Order your pre-assembled AceClamp[®] ML[®]. They come 100 in a box.



STEP #2

Position the AceClamp[®] ML[®] on the standing seam.




STEP #3

Secure AceClamp[®] ML[®] clamp by tightening the easy to reach fasteners.




STEP #4

Torque AceClamp[®] ML[®] with calibrated torque wrench to recommended specs. (See Torque Spec doc or call AceClamp Engineering)



At no time should you use the AceClamp[®] ML[®] as part of your fall protection system!



The management at PMC Industries, Inc. is committed to providing you, our customer the fastest, easiest and safest attachment devices for your snow retention system. We welcome suggestions that will make your job easier.

ACE CLAMP[®]
Innovative Roofing Solutions™

a product of **PMC Industries Inc**

87 Spring Lane Plainville, CT 06062 • P: 860.351.0686 F: 860.351.0689 www.aceclamp.com V061721

*Photos shown are for representative purposes only. Actual product may vary. Design subject to change without notice. Always use OSHA approved safety equipment and procedures when working on a roof. Not responsible for typographical errors.